

# INSTRUCTIONS

## Aluminum Sign Heavy Base Polyester Insert



Includes:  
Double Sided Frame  
Base  
2 Springs  
Screws To Attach

1

Place one spring into one of the two indentations on the top of the base and from the underside thread a washer then a finger screw onto the bolt until finger tight.

2

Repeat for other side.

3

Fill base with water or sand.

4



While unit is laying flat open metal clips and lay graphic in. Then close metal clips smoothing graphic as you go to keep it taut.



This product is for outdoor promotional use only and should not be left out in extreme weather conditions. Please use common sense guidelines and do not display this product outdoors when extreme winds or storms may be present.