

INSTRUCTIONS

Mini X-Banner




Includes:
Banner with Button Holes
X-Banner Frame




1

Stand the frame upright by extending the feet outward.



2

Using your graphic with button holes, attach each of the four corners to the hooks on the X-Banner frame.



3

Ensure that the X-Banner frame is fully extended and taut in order to properly display your graphic.