

INSTRUCTIONS

Vinyl Avenue Banners



Includes:

2 Brackets	2 Caps
2 Poles	4 Quick Release Bands (Clamps)
2 Clevis Pins	2 Zip Ties
2 Retainer Rings	

***Necessary screwdriver not included.
Optional mallet/hammer not included.**



1

Each bracket is marked with a directional arrow. The arrow should be pointing up for the top bracket and down for the bottom bracket.



2

Set the top bracket (with the arrow pointing up) to the desired height on the pole. Secure the bracket in place with two release bands.

Note: A screwdriver must be used to achieve the correct tension.



3

Insert each of the poles firmly into the brackets and twist until the open holes line up.



4

Set the bottom bracket (with the arrow pointing down) to the desired height on the pole. Secure the bracket in place with two release bands.

Note: A screwdriver must be used to achieve the correct tension.



This product is for outdoor promotional use only and should not be left out in extreme weather conditions. Please use common sense guidelines and do not display this product outdoors when extreme winds or storms may be present.



5

Insert the clevis pins through the open hole.
Note: A mallet or hammer may be necessary to tap the pins through each of the holes.



6

Thread the retainer rings through the hole in the end of each of the clevis pins.



7

Place the caps onto the ends of both poles.



8

Slide the banner over the poles and use the zip ties through the retainer rings and grommets to secure the banner in place. Adjust the bottom bracket to ensure that the banner is taut.

